

BASDEN RV CENTER, INC D.B.A. AMERICAN RV
600 E. Baseline Rd.
Evansville, IN
US
47725
812-867-5200

WARRANTY CLAIM # 68088
MANUFACTURER'S CLAIM #:

Manufacturer: 10024 - FOREST RIVER TRAVEL TRAILER
Customer: 52903 - CHAD PETERSON
Address: 7154 HWY 15 MT. CARMEL, IL

62863

Phone: 618-240-9127

Stock Number: 2022 CATALINA

VIN:

Mileage:

Auth. No:

Warr. Date:

HIN:

Work Order Comp: 18 AUG 22

Dealer #:

Work Order Date: 11 AUG 22

SER#: 5ZT2CAYB4NX023676

Inv #: 381447

WO # Job # Description JOB INFORMATION

68088 2 RUN NEW ELECTRIC TO FRONT AC, UNIT WAS SUPOSED TO BE PRE WIRED.
DH CALLED SHARON DECKER 574-825-4995. SHE SAID START WITH 3 HRS
AND CALL BACK
Removed breaker panel to see where wires run through the unit.
Wires run down through the floor and into the underbelly. Removed
rivets that hold underbelly on the frame with a crowbar. Removed
underbelly from the rear of the camper to the first axle. Went
inside and pulled the wall that had the AC prep sticker on it to
see if anything was behind it. Pulled the vent in the bathroom to
see if any wires were running there. Looked several places inside
the ceiling to see where wires were running to see if I could
fish tape them through the unit. Cut open underbelly underneath
master bedroom to help see where the wires come up through the
floor. Remove fireplace from entertainment center to see if there
was any wires leading down into the underbelly to possibly go
that route for a new wire. Wires for fireplace go up through the
wall in the ceiling. Remove monitor panel to see what wires ran
behind it. Went back to the entertainment center in the bedroom.
There is a false wall on the side. Removed panel from the right
side of the entertainment center. Need to drill a hole inside of
this false wall down through the floor and run wire over to the
underbelly and run all the way to the rear of the camper back
through the floor and up to the breaker panel.
Drilled a half inch hole through the floor inside of false wall.
Cut open underbelly fabric in between the J wrap and the frame to
pull wire through the floor. Took a hole saw and went on the

Claim : 68088

WO #	Job #	Description	JOB INFORMATION

		other side of the floor and drilled a hole through so I could then pull the wire through the floor and pull into the underbelly. Take a section of fish tape and secured the wire around it with electrical tape. Pulled wire through the floor and over through the underbelly until I had enough to reach past the rear of the camper. Took fiberglass wire running poles and maneuvered them through the underbelly. Took long section of fish tape and secured it to fiberglass poles and then pulled the fish tape through to the front of the camper just underneath where I drilled the hole in the floor. Removed fiberglass poles. Secured wire to fish tape. Maneuvered wire through the framework and through the underbelly all the way back to the rear of the camper. Took fish tape and ran from the inside compartment where the breaker panel is and down through the floor. Secured wire to fish tape and pulled up through the floor behind breaker panel. Pulled slack out of wire and cut to length. Pulled wire through breaker panel. Went back into bedroom and drilled another hole going through the ceiling inside of the false wall. Took fish tape and ran up through the hole that I drilled in the ceiling. Pulled wire through the ceiling and over to the cutout for the AC. Took jumper wires and multimeter and did a continuity check on the wires to make sure that I did not have any breaks. Installed false wall panel and trim surrounding it secured with Brad nails and filled holes with putty. Took wall next to bathroom and secured it with Brad nails. Took plastic trim that I removed off of that wall panel and applied silicone to the back of it and secured it to the wall. Took a 1x4 and a couple pieces of scrap wood and pushed against the wall to help hold plastic in place as the silicone dries. Secured Batten strips around wall panel and filled holes with putty. Installed monitor panel to the wall. Removed all tools and trash from inside the unit vacuumed floor and bed. Went back outside and taped up underbelly fabric where I had to pull wire through. Went back and secured underbelly to the frame with self tapping Tech screws and washers. Took a 1x4 and cut it to length to fit inside of the frame to add support to the underbelly where I cut it. Secured underbelly to wood with tech screws and washers. Cut a small piece of underbelly material an overlapped the seam. Secured underbelly material to metal cross member and would piece that I added with textures and washers. Secured gas lines where I removed screws. Cleaned up and parked unit.	

Part No	Job#	Description	PARTS	Qty	Price	Total

502163	2	12/2 ROMEX W/GROUND		1.00	132.24	132.24

Claim : 68088

```

*****
Part No      Job#  Description      PARTS      Qty      Price      Total
*****
500627       2    CLEAR SIKASIL PLUS      1.00      8.51      8.51
1119237     2    ADOBE INCAN SEAM TAPE    1.00      0.20      0.20

```

```

*****
Lab Code  Job#  Description      LABOUR      Hrs      Rate      Total
*****
Z990      2    MISC LABOUR CODE (EXTERNAL)    0.50     150.00     75.00
Z990      2    MISC LABOUR CODE (EXTERNAL)    2.50     150.00    375.00
Z990      2    MISC LABOUR CODE (EXTERNAL)    0.75     150.00    112.50
Z990      2    MISC LABOUR CODE (EXTERNAL)    3.00     150.00    450.00
Z990      2    MISC LABOUR CODE (EXTERNAL)    3.75     150.00    562.50
Z990      2    MISC LABOUR CODE (EXTERNAL)    1.50     150.00    225.00

```

```

*****
Excode     Job#  Description      EXTRAS      Qty      Price      Total
*****
FRT        2    UPS - SEAM TAPE    1.00     15.92     15.92

```

```

Parts Total:      140.95
Labour Total:     1,800.00
Sublet Total:      0.00
Extras Total:      15.92

```

>>>> Claim Total: 1,956.87

Customer Signature: _____

Date: _____