

GREENEWAY, INC.
8220 STATE HWY 13 SOUTH
WISCONSIN RAPIDS WI
US
54494
(715) 325-5170

WORK ORDER # 12496

Date In: 04 AUG 25 Author: KOTT
Promised Date: 25 DEC 25 Stock No: 11467
: Year: 2026
Customer Name: 17757 - ORTEGA, JOSEPH Manufacturer: FOREST RIVER
Address: 10261 HUMBOLT STREET Brand: PUMA DESTINATION
: HUNTLEY, IL Model: 403LFT
Postal/Zip: 60142 Miles/Hrs: 0
Phone#(res): 847-331-4495 Exterior Color:
Phone#(bus): Unit Type: TT-TRAVEL TRAILER
Cell Phone: License#:
Email: JOE67USMC@YAHOO.COM Tag#: DB: 9/9
Purchased Date: 25 JUN 25 :
Delivery Date: 25 AUG 25 :
InService Date: :
Serial#: 4X4TPUS25TP106593 :

Job # Description JOB INFORMATION Type Bill To

PDIT COMPLAINT: SOLD COMPLETE PREP I PDI PRE-D
CAUSE: Sold complete prep
CORRECTION: Sold complete prep complete
ZES COMPLAINT: ZONE E- 8 PT BLOCK DELIVERY ADDRESS: I DO DEALE
LAKE WISCONSIN CAMPGROUND - N3204 COUNTY
ROAD V, POYNETTE, WI, 53955 - LOT#42
CAUSE: IN DEAL
CORRECTION: COMPLETE
3 COMPLAINT: ADD GFI IN BATHROOM BEHIND TOILET I DO DEALE
CAUSE: 1001 CUSTOMER REQUESTED I removed the
breaker box and I can see plumbing lines
running through the floor so I took off
the rear screw track and partially
dropped the underbelly. I fed one end
of the wire up through the floor to the
breaker box, taped the other end to the
fishing sticks, and tried to feed it
through the underbelly. The side that
the wire has to be run has all the
drains and wiring so I ended up having
to drop the underbelly on the ODS so I
can run the wire. After I got the wire
run to its location I went inside and
removed the cover for the furnace vent,
removed the screws in the furnace, went
back outside, and took the screws out of
the furnace so I could move it around.
The black tank is right at the edge of

Continued on page 2

Work Order : 12496

Job #	Description	JOB INFORMATION	Type	Bill To	
	the frame and a furnace duct is right next to it so I can't drill a hole in the floor. There is a wire running through the floor just outside the frame so I popped a hole in the underbelly, pulled the wire through, removed the sealant around the wire, and fed the wire up into the unit. There is a black wall panel next to the toilet so I cut a hole in it and fed the wire through. I hooked the wire up to the outlet and secured the outlet to the wall. I went to the breaker box, pulled all the extra wire through, and cut it off. I fed the wire through the box, had to move some wires around to make it fit and when I went to install the breaker it didn't fit. This is a different style breaker so we had to find one that will work. After we found one i hooked it up in the box, turned the power back on, tested the outlet with my outlet tester and everything is working. I put the underbelly back in place and resecured the gas lines. I put wire loom on the exposed piece of wire and secured it to the frame. I filled all the gaps with black silicone. I put the furnace and breaker box back in place and secured them.	8/12 - 11:30 -12:30 1:10 - 4:30 8/13 - 7:25 - 8:00 8:40 - 10:10			
	CORRECTION: Done.				
ST	COMPLAINT: SHOWTHRU&SHOWOUT	SALESMAN: MARK	I	PDI	PRE-D
	CAUSE: Showthru				
	CORRECTION: Showed customers there brand new camper				
CIN	COMPLAINT: CLEAN INTERIOR- NEW		I	PDI	PRE-D
	CAUSE: NEED CLEAN				
	CORRECTION: CLEANED				
CEN	COMPLAINT: CLEAN EXTERIOR- NEW		I	PDI	PRE-D
	CAUSE: NEED CLEAN				
	CORRECTION: CLEANED				
WARR	COMPLAINT: STOVE GRATE WAS BROKE IN HALF UNDER NEATH THE BED MATRESS.		W	1021	FORES
	CAUSE: STEPS FOR THE UNIT WERE PUT ON TOP OF STOVE GRATES FOR TRANSPORT, DURING TRANSPORT THEY MOVED AND STOVE GRATE WAS BROKEN.				
	CORRECTION: ORDER NEW STOVE GRATE AND NEED .1 TO REMOVE AND REPLACE. REPLACEMENT PART				

Continued on page 3

Work Order : 12496

BORROWED FROM VIN # 106631, WHEN RCVD ON THIS PO/RO PLEASE RETURN TO BORROW UNIT. AF WILL NEED TO R&R THE STOVE GRATE. REQUEST .20 HORUS OF LABOR

1 COMPLAINT: WASHER-DRYER-ORDERED ****8/22- DAVE I DO DEALE ORDERED THE WASHER AND DRYER OUTSIDE OF THE WORK ORDER****

CAUSE: 1001 CUSTOMER REQUESTED. I took the drip pan and centered it in the opening, set the washer in place to check the door clearance for the washer and the folding door. Cody and I pulled the washer back out and I screwed the pan to the floor. I used a hole saw to cut out the hole for the dryer vent. I secured the plastic sleeve in place, put the vent cover on, and sealed around it with silicone. I removed the four travel bolts on the back side of the washer, put the washer in the pan, and hooked the water lines up. I measured out where the brackets go on top of the washer, pre-drilled the holes, and secured the brackets. I put the bottom brackets on the feet of the washer, removed the folding door, and Cody and I slid the dryer on top of the washer. Where I originally wanted them to sit won't work with the dryer vent. I had to move the washer and dryer around to make sure there is enough clearance for the water lines, dryer vent, and the opening of the doors. Where it sits I can't secure the bottom feet to the floor because they will stick out past the front of the drip pan. I had to angle the feet in and this style pan has a "dam" that has to be installed to close off the pan. I had to alter the dam, put putty on the back side of it, and secure it to the floor. I put the door back on and turned the washer and dryer on to test them. Cody helped me on and off for an hour.

CORRECTION: Done.

Job #	Part No	Description	PARTS	Bill to	Qty	Price	Total
PDITT	840821034507	12V 24 MDP BATTERY		I-PDI	1	95.88	95.88
ZES	081628593006	FOUNDATION PAD 16" X 18"		I-DO	8	7.98	63.84
ZES	51700202	BLOCK 8" REGULAR 8"		I-DO	30	4.04	121.20
ZES	113997	HARDWOOD WEDGE 5.5"X10.5		I-DO	16	2.24	35.84

Continued on page 4

Work Order : 12496

```
*****
Job # Part No      Description      PARTS  Bill to  Qty    Price    Total
*****
CIN   019079236326  TOILET TISSUE, SGL. 2 PL I-PDI    1      1.02     1.02
CIN   014717396042  HTS STANDARD 10' SEWER H I-PDI    1      7.46     7.46
CIN   019079900142  PARK ADAPTER BULK 30-15 I-PDI    1      2.33     2.33
PDITT 8220BG24      GROUP 24 BATTERY BOX SNA I-PDI    1      9.31     9.31
3     601320118071  BLACK DUAL GFCI OUTLET I-DO    1     55.32    55.32
3     783643148260  20AMP DUPLEX CIRCUIT BRE I-DO    1     43.56    43.56
3     783643148185  SIEMENS CIRCUIT BRK 15AM I-DO    1      9.50     9.50
3     032664666209  RECEPT EXTENTION RING (G I-DO    1      2.87     2.87
CIN   093344312410  ADAPTER 30 AMP MALE TO 5 I-PDI    1     16.47    16.47
WARR0 822085275     RANGE, PART, BACK CAST I W-1021  0      0.00     0.00
1     854812000402  WASHER FRONT LOAD 120V 1 I-DO    1  1,243.22  1,243.22
1     854812000761  STACKABLE KIT FOR FRONT I-DO    1     75.47    75.47
1     822003AB      DELUXE DRYER VENT KIT BL I-DO    1     41.54    41.54
1     8220MK01      SLENDIDE MK01 SECUREFIT I-DO    1     10.40    10.40
1     8220PI22      SPLENDIDE PI-22 DRAIN-A- I-DO    1     47.68    47.68
1     854812000426  DRYER VENTED 120 V 1.9 C I-DO    1  1,004.07  1,004.07
*****
```

```
*****
Job# Lab Code Description      LABOUR  Mech Bill to  Hrs    Rate    Total
*****
PDITT RV1F-3B  SOLD COMPLETE PREP      CF  I-PDI    1.18   70.00   82.60
ZES DEL     ZONE E- STANDARD SET    JT  I-DO    7.86   70.00  550.20
ST RV1D-3   SHOW THRU & PICK UP PD CF  I-PDI    2.00   70.00  140.00
CIN CI      CLEAN INTERIOR          SL  I-PDI    3.65   70.00  255.50
CEN CE      CLEAN EXTERIOR          EJ  I-PDI    1.00   70.00   70.00
3 Z991      MISC CODE (NTERNAL)     JGK I-DO    4.00  140.00  560.00
PDITT RV1F-3B  SOLD COMPLETE PREP      CF  I-PDI    1.93   70.00  135.10
PDITT RV1F-3B  SOLD COMPLETE PREP      CF  I-PDI    1.39   70.00   97.30
3 Z991      MISC CODE (NTERNAL)     JGK I-DO    0.00  140.00   0.00
ARR01 Z992      MISC LABOUR CODE (WARR   W-1021  0.00  140.00   0.00
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    0.00   70.00   0.00
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    0.35   70.00   24.50
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    0.87   70.00   60.90
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    0.13   70.00    9.10
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    1.44   70.00  100.80
1 Z991      MISC CODE (NTERNAL)     JGK I-DO    2.21   70.00  154.70
*****
```

```
*****
Job # Excode Description      EXTRAS  bill to  Qty    Price    Total
*****
PDITT LP      PROPANE                I-PDI    0.00     0.00     0.00
ARR01 FRT      FREIGHT                W-1021   1.00    18.78    18.78
*****
```

```
*****
Type Bill Id      Parts  Labour  Sublet  Extras  Tax    Total
*****
I   DO            2754.51 1460.20  0.00    0.00    0.00  4,214.71
I   PDI            132.47  780.50  0.00    0.00    0.00   912.97
*****
```

Continued on page 5

Work Order : 12496

BILLINGS SUMMARY

Type	Bill Id	Parts	Labour	Sublet	Extras	Tax	Total
W	1021	0.00	0.00	0.00	18.78	0.00	18.78
	Totals	2886.98	2240.70	0.00	18.78	0.00	5,146.46

&k2S
&k0S