

<u>Part</u>	<u>Description</u>	<u>Return Tag #</u>	<u>Qty</u>	<u>Units</u>	<u>Amount</u>
580672 WINDOW 8800 DW 72 X 28 EG G20 TP BK RED	WINDOW 8800 DW 72 X 28 EG G20 TP BK RED		1	1	204.57
960204 Miscellaneous Part for claim use only	Miscellaneous Part for claim use only		1	1	15.96

Operation Line # 3

Flat Rate Code: 720115 Range/Oven - R & R Knob

Fault Code: Component Failure

Problem: Customer states that the sparkler knob on their oven would not turn- when they tried to turn it, it broke.

Hours: .2

Cause: Verified customer concern, the knob does not work.

Amount: 23.00

Remedy: Replaced knob and ignitor.

Sublet Repairs: \$0.00

Manufacturer #: 1

Model #: 1

Serial #: 1

<u>Part</u>	<u>Description</u>	<u>Return Tag #</u>	<u>Qty</u>	<u>Units</u>	<u>Amount</u>
960204 Miscellaneous Part for claim use only	Miscellaneous Part for claim use only		1	1	0.00
960204 Miscellaneous Part for claim use only	Miscellaneous Part for claim use only		1	1	0.00
721294 RANGE OVEN IGNITION KNOB ASSEMBLY ONLY SILVER F/ FGR21G3A2-BG (FURRION C-FGR17G3A2-BG-031)	RANGE OVEN IGNITION KNOB ASSEMBLY ONLY SILVER F/ FGR21G3A2-BG (FURRION C-FGR17G3A2-BG-031)		1	1	0.00
720722 RANGE SPARK IGNITOR ONLY F/ FSRE21SA & FSRE17	RANGE SPARK IGNITOR ONLY F/ 21/17 C-FSRE21SA-020		1	1	0.00