



Alix Mongiat <alix@dealer-advisors.com>

PA 863391

Sonya Gallagher <sgallagher@granddesignrv.com>
To: Alix Mongiat <alix@dealer-advisors.com>
Cc: Michael Shearer <mshearer@granddesignrv.com>

Thu, May 22, 2025 at 3:10 PM

Alix,

I do not have any documentation stating that law. Please provide a copy for my review. We would like to assist you in this repair. Here are

Troubleshooting Steps:

1. **Check the voltage:** Measure the voltage at the battery terminals while driving to see if the alternator is charging.
2. **Inspect the isolator solenoid:** If the alternator is charging but the batteries aren't, the isolator solenoid might be faulty.
3. **Test the batteries:** Have the batteries professionally tested to assess their condition.
4. **Identify parasitic loads:** Check for any lights, devices, or other appliances that might be draining power.
5. **Clean and secure connections:** Ensure all connections, including battery terminals, are clean and tight.

Let me know if you have any questions,

Have a good day!

[Quoted text hidden]