

WARRANTY

Does compressor run? Yes No

Starting Amps: _____ AC Volts: _____ DC Volts: 13.6

If 12V

Wire Length: 30' Size: 8 awg

With refrigerator running (battery only), What is the voltage drop between the battery and Refrigerator Terminal Block? .1 Compressor won't start

With converter on (shore power), What is the voltage drop between the Battery and Refrigerator Terminal Block? .1 Compressor won't start

Does light operate? Yes No

Does door seal and latch properly (If equipped)? Yes No

Is there airflow through the front vent (Use piece of paper to check)? Yes No

Does compressor cycle on and off? Yes No

Temperature Checks

Temp control set to mid setting

Ambient temperature in RV: 72

Prior to Operating

Fresh Food: 76 Freezer: 77

Wine Compartment (14CUFT only): _____

After 2 Hour Run Time

Fresh Food: 77 Freezer: 79

Wine Compartment (14CUFT only): _____

Amp Draw: .6

Please note: Submitting this form does not guarantee your claim will be paid or replacement will be issued. Furrion may request additional details based on the documentation you have completed.